



MIXING INSTRUCTIONS

****ALL INGREDIENTS ARE PREMEASURED**

Step 1: REPAIR AREA MUST BE CLEAN AND DRY!

Step 2: Mix Part A with Part B in the pail supplied for 30 seconds....Then introduce the aggregate and then blend into a homogenous state for approx. 30-45 seconds.

Step 3: Once you reach the desired consistency, apply the product to your project.
Pot life is 15 minutes

Step 4: This is a Trowel-able product. Reminder **Pot life is 15 minutes**

Step 5: Cure times vary per product – refer to product page for individual cure times at mipco.org

WWW.MIPCO.ORG